

# Touch<sub>2</sub>O<sup>TM</sup>.xt Proximity Setting

## **HANDS FREE PROXIMITY™**

1. Hands free mode may be de-activated or activated. To re-activate or de-activate hands free please perform tap sequence on your faucet:
  - a. Put the handle in off position
  - b. Do not touch faucet for 10 seconds
  - c. Tap faucet 6 times within 4 seconds
  - d. Wait for red/blue light to stop flashing
  - e. Tap the faucet again 6 times within 4 seconds (this step must be completed within 4 seconds of step D above.
  - f. Red/blue light flashes to confirm hands free mode is activated
  - g. If you do not see red/blue flashes during these steps then the change has not been programmed – please wait 10 seconds and repeat these steps.